



## **BVT PARQUET INSTALLATION GUIDE**

### **Controlling unevenness and remaining humidity**

Before you begin with the installation, assure that residual moisture is no more than %1,5 contained in new brought subfloor. The underground is to be examined with an adjustment lath for unevenness. Should unevenness more than 5mm to 1,5m length be determined, these must be smoothed with an appropriate balance spatula.

### **Installation**

Takes the swimming installation place on an old timber underlay subfloor, the parquets should be placed in transverse direction to the old ones. The first floorboard is to place with its both grooved sides looking to the wall. In order to ensure a continuous wall distance of at least 10mm all around, supplements and wedges from wood to be used. With very bent walls the boards must be adapted to the wall curvatures.

Please hold the bottle of Aicher Spritzlein glue on oblique and lay glue on continuously in the forehead and longitudinal groove. The surplus glue coming from the joint can be wiped away easily with a rag and don't harm the lacquer.

### **Please keep attention**

Take care by laminate to lay glue on the tongue. Let surplus glue step out and remove it after drying with a plastic spatula.

### **Installation Technique**

The front joint of each new placed parquet has to be inserted first with light knocks on the opposite face of the other parquet. Only the front joint fits exactly, the long side of the parquet shall be joined. Please exclusively knock on the tongue sides of the parquets, never otherwise! Apply the knocks to joints of the parquet pushing in direction of the frontal tongue.

After the glue is dried, all wedges all around are removed. The stretch gaps are appropriately covered with a skirting board, which is fixed to the wall with appropriate dowels and screws. Skirting never fasten to parquet.